



**Power Button** – The Scout camera has 3 power modes: On, Off, and Standby.

- On - Takes approximately 90 seconds (during bootup there is a fast-flashing red LED on the eyepiece display).
- Standby - After the camera is on, pressing the Power button will toggle the camera between On and Standby mode. (In Standby there is a slow-flashing red LED on the eyepiece display.)
- Off - Push and hold the power button for 8 sec. to turn off.

**Capture Button** – When enabled, takes snapshots (press and release) or video clips (press and hold 3 seconds to start video recording). The files are stored on the integrated SD card..

**Display Brightness** – Toggle through five brightness settings.

**White/Black Hot/Instalert** – In White Hot, hotter items appear as white or light grey. In the Black Hot, hotter items appear as black or dark grey. In Instalert, hot items in a scene are outlined in red.

**2x Zoom** – When enabled, causes the image to zoom to 2X.

**Diopter Controls** – The diopter adjustment knob allows a  $\pm 2$  diopter range.



**NetZeroTools**  
800-577-6389

[www.netzerotools.com](http://www.netzerotools.com)



## Installing the Batteries and SD Card


The batteries must be installed and charged before using your camera. Install your SD card.

1. Remove the small SD card cover.  
No tools are required.
2. Install the SD card.



Battery cover

Grasp SD card cover edges and pull



3. Loosen the four captive screws securing the battery cover.

4. Pry off the battery cover by grasping the front edge where the SD card cover was removed.

5. Install the batteries as shown.

6. Snap the SD card cover back into place and re-install the battery cover—it only fits one way.

## Charging the Camera

The batteries in the camera must be charged prior to their first use.

1. Connect the Hot Shoe to your camera.
2. Ensure that the plug is fully seated in the Hot Shoe.

When charging correctly, the charging indicator will be lit yellow and will blink green for one second within about 35 seconds.

The charging indicator will continue to blink at decreasing intervals until the batteries are fully charged.

When fully charged, the charging indicator will be lit solid green. The initial charge time is approximately 4 hours.

Plug from power adapter

Charging indicator



Solid green



[Flir TS24 TS 24 Pro Scout Thermal Imaging Night Vision Infrared Camera](#)  
[Flir TS24 TS 24 Scout Thermal Imaging Night Vision Infrared Camera](#)  
[Flir TS32 TS 32 Pro Scout Thermal Imaging Night Vision Infrared Camera](#)  
[Flir TS32 TS 32 Scout Thermal Imaging Night Vision Infrared Camera](#)  
[Flir TS32r TS 32r Pro Scout Thermal Night Vision Infrared Camera](#)  
[Flir TS32r TS 32r Scout Thermal Imaging Night Vision Infrared Camera](#)

