

Indoor and Outdoor Enclosed Safety Shower Storage and Preservation Guide

Installation

A Bradley Enclosed Safety Shower is a portable investment toward workplace safety. The storage and preservation guide consists of instructions and warnings to help care for the new enclosed safety shower. Read the guide thoroughly, contact Bradley Corporation technical services directly should there be additional questions.

The Storage and Preservation Guide addresses the storage and preservation of enclosures prior to the initial installation, and only applies to Bradley Enclosed Safety Showers.

⚠ CAUTION: Note center of gravity marking on the exterior of the crate. Use caution when transporting and use proper lifting techniques.

Warning!

⚠ DO NOT stack product.

⚠ DO NOT use bleach or any corrosive material to clean the components inside the enclosure. Bradley recommends using mild detergent.

⚠ DO NOT transport the S19374 or the S19384 with water in the tank (if repositioning the unit).

⚠ Piping within the enclosure contains approximately 4 liters (1.06 gallons) of RV anti-freeze inside the system to prevent freezing. Flush the system for a minimum of 30 minutes to ensure antifreeze has been completely eliminated from the system.

Base Model No.	Description	Approx. Crated Weight (lbs.)	Crated Dimensions
S19372	Indoor – Tepid Water Inlet – Hot Water Tank	700	72"L x 96"W x 120"H
S19374	Indoor – Hot Water Tank	1,925	72"L x 138"W x 120"H
S19376	Indoor – Self Contained Water Tank	1,925	72"L x 144"W x 120"H
S19378	Indoor – Electric Tankless Water Heater	2,200	72"L x 138"W x 120"H
S19382	Outdoor – Tepid Water Inlet	800	72"L x 96"W x 120"H
S19384	Outdoor – Hot Water Tank	2,525	72"L x 138"W x 120"H
S19386	Outdoor – Self Contained Water Tank	2,525	72"L x 144"W x 120"H
S19388	Outdoor – Electric Tankless Water Heater	2,800	72"L x 138"W x 120"H

Water ports and exterior drain are plugged to prevent entrance of debris, animals or other foreign material. Swinging doors are secured shut with a cable tie to prevent unauthorized entrants or animals from damaging the interior components of the shower.

Instructions

- Interior and exterior of enclosure can be washed using a hose with a soft brush on a low pressure setting.
- Product must be stored in an upright position. Note arrows on the exterior of the packing crate.
- Store the enclosure in a secure and temperature controlled environment.
- Make sure the eyewash or eye/face wash dust covers are covering the spray head nozzles.
- Locate the shower on a cement resting pad that is at least 6" larger in its overall dimension than the perimeter of the enclosure. See Bradley's preconstruction guide for manufacturer recommended dimensions.

[Bradley S19372 Indoor Enclosed Safety Shower](#)

[Bradley S19374 Indoor Enclosed Safety Shower](#)

[Bradley S19378 Indoor Enclosed Safety Shower](#)